

## Faraday Cup Wiring

Beam current and bias BNC feedthroughs are mounted on the unit or supplied with a stand-alone cup assembly

The Faraday cup current connection is available through the BNC vacuum feedthrough marked <u>SIG</u>

The bias supply should be connected to the BNC vacuum feedthrough marked  $\underline{B}$  for secondary electron suppression.

#### Caution

#### PHOSPHOR SCREEN SURFACE IS DELICATE AND ULTRA HIGH VACUUM CLEAN.

# STAINLESS COVER TO BE REMOVED ONLY BY QUALIFIED CLEAN ROOM TECHNICIAN.

### DO NOT TOUCH PHOSPHOR SURFACE.